

chillcheck[®]

Temperature Indicators for Walk-in Fridges, Freezers and Cold Store Rooms

chillcheck[®]

Food Temperature
Monitoring



COLD

TOO WARM



WARNING DISPLAY

A fast, simple temperature monitoring system based on proprietary colour change technology

- Reveals real time air and food temperature
- Easy to read. The warning symbol appears green only when immediate cold room temperature rises above the preset activation point
- Large Indicators (175 x 240mm)
- For coldrooms (walk-in fridges and freezers) Temperatures available : 4C, 5C, 8C, 12C and F
- Provides due diligence information
- No power or maintenance required
- Instant visible temperature change
- Allows you to meet Food Safety Requirements and HACCP Guidelines to be met

Temperature control and measurement is a key factor in product quality, hygiene and safety. Checking temperatures and recording them are essential to ensuring that a working HACCP system can be demonstrated. These large temperature indicators incorporate specialist thermochromic liquid crystal technology and are specially developed to monitor the cold air and food temperature within commercial walk in fridges, freezers and cold food storage rooms allowing retailers and organisations to meet HACCP and Food Safety Regulations.

They are easily positioned and instantly visible for quick temperature monitoring of a cold store room. The easy to read warning symbol appears in green only when the cold room temperature rises above the preset activation point warning that temperatures are critical for cold food storage. The indicators remaining black when at the correct temperature.

chillcheck[®] Indicators for Walk-in Fridges, Freezers and Cold Store Rooms

Code	Description	Temp	Size	Supplied
L01LCRVR-15C01LS	Large Freezer Indicator	-15°C	240mm x175mm	Single
L01LCRVR004C01LS	Large Chiller Indicator	4°C	240mm x175mm	Single
L01LCRVR005C01LS	Large Chiller Indicator	5°C	240mm x175mm	Single
L01LCRVR008C01LS	Large Chiller Indicator	8°C	240mm x175mm	Single

Instructions for use:

1. Place temperature indicator on wall under chiller fans or in close proximity and as far away from the entrance.
2. Check regularly. If Chiller/Freezer Monitor remains black, temperature is still correctly below activation point.
3. If Chiller/Freezer Monitor turns green it is a warning that the storage temperature is too warm.